

-This shirt skims the body
-Note that Chest (A) and Waist (B) are taken on the body
while Length (C) through Hem (G) are flat garment measurements
-When measuring if you land in between two sizes choose the size
that represents your chest measurement
-Measure yourself for sizing for best results as all retailers use
different measurements for their sizing

Mens Solar Long Sleeve Flat Garment Specifications

Vapor Size

XS

S

M

L

XL

XXL

XXXL

XXXXL

	Length (C)	Neck Width (D)	Flat Chest (E)	Sleeve Length (F)	Hem (G)
XS	66cm	17.75cm	52cm	62.25cm	50.8cm
S	68.5cm	17.75cm	53.3cm	62.8cm	53.3cm
М	71cm	17.75cm	55.8cm	63.5cm	55.8cm
L	72.4cm	17.75cm	58.5cm	64.75cm	58.5cm
XL	76.2cm	19.7cm	61cm	65.5cm	61cm
XXL	80cm	20.3cm	63.5cm	66cm	62.25cm
XXXL	81.25cm	20.3cm	64.75cm	66cm	63.5cm
XXXXL	85cm	22.25cm	67.3cm	68.5cm	66cm

HOW TO MEASURE ON THE FLAT...

Length (C) - Hold tape measure at highest point on shirt and pull tape down to the bottom of the hem

Neck Width (D) - Hold tape measure at one side of neck hem and pull to the other side

Flat Chest (E) - Hold tape measure under armhole and pull to the other side

Sleeve Length (F) - Hold tape measure at the top of the armhole seam and pull to bottom of sleeve hem

Hem (G) - Hold tape measure at side seam and pull to the other side